FIG. 1



FIG. 2



FIG. 3



FIG. 4


START
401
POWER ON
402
COAT PURE WATER ONTO BRUSH
403
ALIGN POSITION AND INSERT DISC
DISC LOADED
404
ATTEMPT TO FOCUS
405
FOCUS ERROR
406
DEVICE HALTED
407
CLEANING OF OBJECT LENS BY BACK AND FORTH OPERATION OF DISC
408
EJECT COMMAND
DISC EJECTED
409
REMOVE DISC
END

FIG. 5



FIG. 6



FIG. 7



FIG. 8